

Best Management Products, Inc.

U.S.. Patent # 6126817 Canadian Patent #2285146

72RTB96" SNOOT®

INSTALLATION INSTRUCTIONS

A 72" SNOOT will fit over a pipe with an outside diameter up to 72". This SNOOT is built for a 96" diameter structure.

1. The 72RTB96 SNOOT Oil & Debris Stop is shipped knocked down in two parts or three parts. Therefore it will be necessary to site assemble the parts. Use the supplied gaskets to make connections between the parts of the SNOOT and the SNOOT & the wall of the structure.
Over-lap any intersecting gaskets approximately 1" to insure a good seal.
 - (1) Stand base section upright & install PSA-backed gaskets to the top flange.
 - (2) Place dome part on the base section and temporarily clamp together to align.
 - (3) Locate seven (7) evenly spaced bolt locations along connecting flanges.
 - (4) Drill seven (7) holes to receive the 1" x 3/8" SS bolts, nuts and washers. Remove clamps.
 - (5) Bolt the dome to the base after lowering the two halves into the structure.
2. Center the SNOOT directly over the outlet pipe so that the entire pipe is covered and the lower edge of the hood is at least 1/2 the pipe diameter below the lowest inside point of the pipe (deeper is even better).
3. Drill equally spaced 7/16" holes through the SNOOT flange (8 in top, 6 in each base section).
4. Mark and drill catch basin and install the tamp-in lead expansion anchors.
 - (1) Drill a 3/4" hole into the base material to the required depth (approximately 1-1/4" deep.)
 - (2) Blow the hole clean of dust and other material.
 - (3) Insert the anchor into the hole. Narrow end of cone must point out, lead shield slides over cone.
 - (4) Position the setting tool or a 9/16 socket against the anchor outer cone. (The outer rim of the tool or socket should seat onto the lead shield rim). Set the anchor by driving the lead sleeve over the cone using several sharp hammer blows. Be sure the anchor is at the required embedment depth (flush or slightly below face of concrete).
5. Attach the 2" vent pipe adapter in the predrilled hole in the top of the SNOOT using the 2 flat O-ring gaskets and PVC lock-nut supplied in kit. Install with the female pipe adapter up and a washer on each side of the SNOOT shell. Tighten lock-nut hand tight.
6. Remove PSA backing and with firm pressure, attach gasket strip to back of SNOOT flange and trim excess.
7. Attach the SNOOT to the catch basin wall with 3/8" diameter stainless steel bolts. Do not over tighten; 10-15 foot pounds should be sufficient.
8. Cut the anti-siphon vent stack to length and attach to hood at the female pipe adapter with PVC cement.
9. Attach 90 degree elbow to vent stack with PVC cement. Ensure that the elbow opening is accessible for maintenance and inspection.

SNOOT 72RTB96

Installation Kit Items

- (7) 3/8 x 1.5" stainless steel bolts
- (14) 3/8" stainless steel washers
- (7) 3/8" stainless steel nuts
- (1) 90 degree elbow

- (16) expansion anchor assemblies
- (1) 2" female pipe adapter
- (2) neoprene O rings
- (1) 2" PVC lock-nut.
- (4) 9 foot PSA backed gasket strip
- (1) 2" x 12" length PVC pipe

Check packing materials for all items!!!

VISIT OUR WEBSITE WWW.BMPINC.COM

Installation Instructions for all SNOOT® products are available on the BMP Website